

F-800 泥浆泵配件

序号	产品图号	产品名称	单位	备注
1	AH34001-01.01.30	密封垫环	件	Gasket
2	AH34001-02.18	挡板	件	Retainer
3	AH34001-03.03	耐磨套	件	Oil Seal Wear Ring (wear plate)
4	AH34001-03.04	端盖	件	Cover
5	AH34001-03.05	密封垫圈	件	Gasket
6	AH34001-03.06	密封垫圈	件	Gasket
7	AH34001-03.10A	油封	件	Oil Seal
8	AH34001-04.01	十字头	件	Crosshead
9	AH34001-04.02	上导板	件	Crosshead Guide(Upper)
10	AH34001-04.04	填料盒	件	Stuffing Box
11	AH34001-04.06A	密封环	件	Sealing Ring
12	AH34001-04.07	挡泥板	件	Baffle
13	AH34001-04.08	中间拉杆	件	Crosshead Extension
14	AH34001-04.09	十字头销	件	Crosshead Pin
15	AH34001-04.11	下导板	件	Crosshead Guide(lower)
16	AH34001-04.15	锁紧弹簧	件	Lock Spring
17	AH34001-04.19	密封垫	件	Gasket
18	AH34001-04.23A	双唇油封	件	Double Lip Oil Seal
19	AH34001-05.02A	活塞杆	件	Piston Rod
20	AH34001-05.04.00	卡箍总成	件	Piston Rod Clamp
21	AH34001-05.07A.00	吸入空气包	件	Suction Damper
22	AH34001-05.07A.02	胶囊	件	Capsule
23	AH34001-08B.00	喷淋泵总成	件	Piston and Liner Wash (Spray Pump Assy.)
24	AH34001-12	密封垫	件	Gasket
25	AH34001-14	密封垫	件	Gasket

F-1000 泥浆泵配件

序号	产品图号	产品名称	单位	备注
1	AH33001-05.01A	液缸		Fluid End Studded Assy.

2	AH33001-02.03	密封垫圈	件	Gasket
3	AH33001-02.15	挡圈	件	Outer Race Retainer
4	AH33001-02.17	挡板	件	Inner Race Retainer
5	AH33001-03.03	耐磨套	件	Oil Seal Wear Ring (Wear Plate)
6	AH33001-03.05	密封垫圈	件	Gasket
7	AH33001-03.11	油封	件	Oil Seal
8	AH33001-04.01	十字头	件	Crosshead
9	AH33001-04.02	上导板	件	Crosshead Guide (Upper)
10	AH33001-04.04	填料盒	件	Stuffing Box
11	AH33001-04.06A	密封环	件	Sealing Ring
12	AH33001-04.08	挡泥板	件	Fluid Baffle back-up Plate (Baffle)
13	AH33001-04.09	中间拉杆	件	Crosshead Extension
14	AH33001-04.12	下导板	件	Crosshead Guide(lower)
15	AH33001-04.13A	固紧板	件	Locking Plate
16	AH33001-04.16	锁紧弹簧	件	Lock Spring
17	AH33001-04.20	密封垫	件	Gasket
18	AH33001-04.24A	双唇油封	件	Double Lip Oil Seal
19	AH33001-05.02	缸盖法兰	件	Thread Ring
20	AH33001-05.03A	缸盖	件	Cylinder Cover
21	AH33001-05.04	缸套密封圈	件	Liner seal
22	AH33001-05.05	缸盖堵头	件	Cylinder Head Plug
23	AH33001-05.06	顶缸器	件	Pressing Sleeve
24	AH33001-05.09	阀盖密封圈	件	Valve Cover Seal
25	AH33001-05.11A	阀盖	件	Valve Cover
26	AH33001-05.12	阀杆导向器（上）	件	Valve Guide（Upper）
27	AH33001-05.13.00	弹簧导向	件	Spring Guide
28	AH33001-05.14	挡板	件	Retainer
29	AH33001-05.16	阀弹簧	件	Valve Spring
32	AH33001-05.17.01.03	阀体总成	件	Valve Body Assy.
33	AH33001-05.17.02	阀螺母	件	Valve Nut
34	AH33001-05.17.03	阀胶皮	件	Valve Insert

35	AH33001-05.17.04	阀座	件	Valve Seat
36	AH33001-05.18.00A	活塞螺母	件	Piston Nut
37	AH33001-05.19.01.00	活塞 ￠ 120	件	Piston ￠ 120
38	AH33001-05.19.02.00	活塞 ￠ 130	件	Piston ￠ 130
39	AH33001-05.19.03.00	活塞 ￠ 140	件	Piston ￠ 140
40	AH33001-05.19.04.00	活塞 ￠ 150	件	Piston ￠ 150
41	AH33001-05.19.05.00	活塞 ￠ 160	件	Piston ￠ 160
42	AH35001-05.19.06.00	活塞 ￠ 170	件	Piston ￠ 170
43	AH33001-05.19.07.00	活塞 ￠ 100	件	Piston ￠ 100
44	AH33001-05.19.08.00	活塞 ￠ 110	件	Piston ￠ 110
45	AH33001-05.20A	活塞密封圈	件	Piston Seal
46	AH33001-05.21A	活塞杆	件	Piston Rod
47	AH33001-05.24.00	卡箍总成	件	Piston Rod Clamp
48	AH33001-05.27	缸套端盖	件	Liner End Cover
49	AH33001-05.30	固定卡	件	Liner Cage
50	AH33001-05.31.00	阀杆导向器 (下)	件	Valve Guide (Lower)
51	AH33001-05.35.00	吸入空气包	件	Suction Damper
52	AH33001-05.35A.02	胶囊	件	Capsule
53	AH33001-08C.00	喷淋泵总成	件	Piston and Liner Wash (Spray Pump Assy.)
54	AH33001-09	密封垫圈	件	Gasket
55	AH33001-15	密封垫	件	Gasket
56	AH33001-25	密封垫	件	Gasket
57	AH30001-31.06.00	顶缸器取出工具	件	Pressing Sleeve Pulling Tool
58	AH33001-31.09.00A	液压拔阀器	件	Valve Seat Puller
59	AH33001-31.10.04	密封垫	件	Gasket
60	AH33001-31.10.05	丝堵	件	Screw Plug
61	AH33001-37.00A	盖板总成	件	Cover Assy.